


AY01 Installation Diagram



Note:

1. Don't cote it any paint to prevent interference with transmission and reception.
2. AY01 is a horizontal directional transmission. It can be used at an elevation Angle for environmental needs.